

1. 19.5V 6.0*4.4 SONY

Compatible with the following Sony Series:

Sony Vaio PCG-700, PCG-800, PCG-900, PCG-F, PCG-FR, PCG-FX,

PCG-FXA, PCG-QR, PCG-XE, PCG-XG, PCG-XR, PCG-XG, PCG-Z Series

Sony VAIO PCG-705, PCG-707, PCG-717, PCG-719, PCG-729, PCG-731, PCG-735,
PCG-748, PCG-808, PCG-812, PCG-818, PCG-838

Sony VAIO PCG-XG9, PCG-XG500, PCG-XG700, PCG-XG18, PCG-XG19, PCG-XG28,
PCG-XG29, PCG-XG38, PCG-XG39

Sony VAIO PCG-FX120, PCG-FX140, PCG-FX150, PCG-FX170

Sony VAIO PCG-F150, PCG-F160, PCG-F180, PCG-F190, PCG-F250, PCG-F270, PCG-F280,
PCG-F290, PCG-F340, PCG-F350, PCG-F360, PCG-F370, PCG-F390, PCG-F430,
PCG-F450, PCG-F480, PCG-F490, PCG-F520, PCG-F540, PCG-F560, PCG-F580,
PCG-F590, PCG-F610, PCG-F630, PCG-F650, PCG-F680, PCG-F690

Sony VAIO PCG-R505TS, PCG-R505TE

Sony VAIO PCG-Z505LS, PCG-Z505LE, PCG-Z505JS, PCG-Z505JE, PCG-Z505HS,
PCG-Z505HE

2. 19V 5.0*1.0 SAMSUNG

Compatible with laptop models:

Samsung A10, GT9000, M50, M55, M70, P10, P20, NP20, P25, P30, P35, NP25,
P40, P50, P60, R65, T10, V20, V25, X20, X25, X50, X60

Samsung Sens 630

Samsung Sens 820

Samsung Sens Pro 680

Samsung Sens Pro 850

Samsung MetroBook Series:

MetroBook MetroBook LT

MetroBook VL

MPC (formerly MicronPC) TransPort series:

MPC (formerly MicronPC) TransPort GX

MPC (formerly MicronPC) TransPort GX+

MPC (formerly MicronPC) TransPort GX2

MPC (formerly MicronPC) TransPort GX3

MPC (formerly MicronPC) TransPort LT

MPC (formerly MicronPC) TransPort VX

MPC (formerly MicronPC) TransPort XT

MPC (formerly MicronPC) TransPort XT2

MPC (formerly MicronPC) TransPort ZX

Samsung GT6000 Series

Samsung GT6330 Samsung GT6330XT Samsung GT6360 Samsung GT6360XT Samsung
GT6400 Samsung GT6400XV

Samsung GT7000 Series

Samsung GT7000

Samsung GT7700

Samsung GT8000 Series Samsung GT8000 Samsung GT8600 Samsung GT8600XT
Samsung GT8650 Samsung GT8650XT Samsung GT8700 Samsung GT8700XT Samsung
GT8750 Samsung GT8750XT Samsung GT8750XV Samsung GT8800 Samsung GT8800XT
Samsung GT8800XV Samsung GT8850 Samsung GT8850XT Samsung GT8850XTD
Samsung GT8900 Samsung GT8900DXV Samsung GT8900XTR Samsung GT8910
Samsung GT8910KXV

Samsung GT9000 Series

Samsung GT9000

Samsung GT9000 PRO

Samsung VM6000 - VM8000 Series

VM6000, VM6300, VM6300CT, VM7000, VM7550, VM7550CT, VM7650, VM7650CT,
VM7650CXTD,

VM7600, VM7600CT, VM7700, VM7700XTD, VM8000, VM8080, VM8080CXT, VM8090,

VM8090CT, VM8090CXTD, VM8100, VM8100CX, VM8100CXTD, VM8110CXTD,
VM8110XTC,

Samsung X05 ,Samsung X10 ,Samsung X15 ,Samsung X20 ,Samsung X30
Samsung Aquila X05 Series ,Samsung Aquila X10 Series
Samsung P28 series ,Samsung P30 series ,Samsung P35 series
Samsung M40 series SPA-X19/E ,Samsung M40 series SPA-X19

Samsung Corona P30 Series
Samsung GS6000
Samsung CM7000 series

3. 16V 5.5*2.5 IBM

- **Compatible with laptop models:**

IBM Part number:

02K0077, 02K5669, 02K6542, 02K6543, 02K6544, 02K6545, 02K6547, 02K6548,
02K6549, 02K6550, 02K6554, 02K6555, 02K6557,
02K6654, 02K6657, 02K6658, 02K6661, 02K6665, 02K6666, 02K6669, 02K6670,
02K6671, 02K6673, 02K6674, 02K6677, 02K6699,
02K6700, 02K6701, 02K6702, 02K6703, 02K6704, 02K6705, 02K6706, 02K6707,
02K6708, 02K6709, 02K6744, 02K6746, 02K6747,
02K6749, 02K6750, 02K6751, 02K6753, 02K6754, 02K6756, 02K6757, 02K6808,
02K6809, 02K6810, 02K6813, 02K6814, 02K6815,
02K6816, 02K6880, 02K6881, 02K6882, 02K6883, 02K6884, 02K6886, 02K6887,
02K6888, 02K6889, 02K6890, 02K6891, 02K7006,
02K7007, 02K7010, 02K7011, 02K7654, 04H4020, 04H6903, 08K8202, 08K8203,
08K8204, 08K8205, 08K8206, 08K8207, 08K8208,
08K8209, 08K8210, 08K8211, 08K8212, 08K8213, 10K0150, 10K0151, 10K3820,
11J8956, 11J8974, 12J1443, 12J1444, 22P7091,
22P7092, 22P9003, 22P9009, 22P9010, 22P9021, 24P0151, 31P3975, 36H6340,
40Y7682, 59G7988, 59G7991, 73G3393, 73G3411,
73P4485, 73P4502, 73P4503, 73P4510, 76H0139, 82K8209, 82K8212, 83H6339,
83H6739, 85G6675, 85G6696, 85G6698, 85G6700,
85G6706, 85G6707, 85G6719, 85G6736, 85G6737, 85G6738, 92P1015, 92P1016,
92P1017, 92P1019, 92P1020, 92P1021, 92P1023,
92P1024, 92P1025, 92P5014, 93P5014, 93P5015, 93P5017, 93P5024, 93P5025,
CF-AA1623, CF-AA1623A, CF-AA1623AM, CF-AA1623M

- **Compatible with follow Series:**

IBM ThinkPad Models:

130, 235, 240, 240X, 240Z, 390, 340, 345, 360, 370, 380, 365, 365C, 365CD, 365CS,

365CSD, 365E, 365ED, 365X, 365XD, 380,
380D, 380E, 380ED, 380XD, 380Z, 385, 385CD, 385D, 385ED, 385XD, 390X, 535,
550, 560, 560C, 560E, 560X, 560Z, 570, 570E,
600, 600E, 600X, 701, 701C, 701CS, 770, 770E, 770ED, 770X, 770Z

A Series:

A20, A20M, A20P, A21, A21E, A21M, A21P, A22E, A22M, A22P, A30, A30P, A31,
A31P

E Series:

E530

i Series:

i-1200, i-1210, i-1211, i-1241, i-1251, i-1271, i-1300, i-1321, i-1340, i-1351, i-1351,
i-1391, i-1418, i-1420, i-1421,
1441, i-1442, 1460, 1480, i-1482, i-1500, i-1700, i-1720, i-1721, i-1351, i-1361, i-1391

R series:

R30, R31, R32, R40, R40E, R50, R50E, R50P, R51, R52

T Series:

T20, T21, T22, T23, T30, T40, T40P, T41, T41P, T42, T42P, T43

X Series:

X20, X21, X22, X23, X24, X30, X31, X40, X41

- Replace Part Number:

02K6543, 02K6548, 02K6553, 01H6136 , 02K5669 , 02K6491 , 02K6496 , 02K6545 ,
02K6549 , 02K6550, 02K6555 , 02K6556 , 02K6557 , 02K6654 , 02K6657 , 02K6658 ,
02K6661, 02K6665 , 02K6666, 02K6669 , 02K6670 , 02K6671 , 02K6673 , 02K6674,
02K6677 , 02K6699 , 02K6701 , 02K6702 , 02K6703 , 02K6704 , 02K6705, 02K6706 ,
02K6707 , 02K6708 , 02K6709 , 02K6744 , 02K6746 , 02K6746, 02K6747 , 02K6749 ,
02K6750 , 02K6751, 02K6753 , 02K6756 , 02K6757, 02K6807 , 02K6809 , 02K6813 ,
02K6880 , 02K7006 , 02K7010 , 02K7011 , 02K7654 , 08K8202 , 08K8203 , 08K8204 ,
08K8205 , 08K8206 , 08K8207 , 08K8208 , 08K8209 , 08K8210 , 08K8211 , 08K8212 ,
08K8213 , 11J8626 , 11J8702 , 11J8956 , 12H1441 , 12J0538 , 12J1441 , 22P9010 , 24P0151 ,
40Y7682, 82K8209 , 82K8212 , 85G6695 , 85G6698 , 85G6737 , 83H6339 ,
92P1015 , 92P1017 , 92P1019 , 92P1021 , 92P1023 , 92P1025

- Fit Laptop models:

- Thinkpad 235, Thinkpad 240, Thinkpad 240X, Thinkpad 240Z, Thinkpad 290, Thinkpad 310, Thinkpad 365, ThinkPad 365C, ThinkPad 365CD, ThinkPad 365CS, ThinkPad 365CSD, ThinkPad 365E, ThinkPad 365ED, ThinkPad 365X, ThinkPad 365XD, ThinkPad 380 , ThinkPad 380D, ThinkPad 380D-MMX, ThinkPad 380E, ThinkPad 380ED, ThinkPad 380XD, ThinkPad 380Z, ThinkPad 385, ThinkPad 385CD , ThinkPad 385D, ThinkPad 385D-MMX, ThinkPad 385ED, ThinkPad 385XD, ThinkPad 390, ThinkPad 390E, ThinkPad 390X, Thinkpad 500, ThinkPad 535, ThinkPad 550, ThinkPad 560, ThinkPad 560C, ThinkPad 560E , ThinkPad 560X, ThinkPad 560Z, ThinkPad 570, ThinkPad 570E , ThinkPad 600, ThinkPad 600A, ThinkPad 600E, ThinkPad 600X , ThinkPad 701, ThinkPad 701C, ThinkPad 701CS, ThinkPad 770 , ThinkPad 770E, ThinkPad 770ED, ThinkPad 770X, ThinkPad 770Z , ThinkPad A20, ThinkPad A20M, ThinkPad A20P, ThinkPad A21, ThinkPad A21e, ThinkPad A21M, ThinkPad A21P, ThinkPad A22, ThinkPad A22e, ThinkPad A22M, ThinkPad A22P, ThinkPad A30, ThinkPad A30P , ThinkPad A31, ThinkPad A31p, Thinkpad E530, ThinkPad i1100, ThinkPad i1200, ThinkPad i1210, ThinkPad i1211, ThinkPad i1241, ThinkPad i1251 , ThinkPad i1271, ThinkPad i1300 , ThinkPad i1321, ThinkPad i1340 , ThinkPad i1351, ThinkPad i1361, ThinkPad i1391, ThinkPad i1418 , ThinkPad i1420, ThinkPad i1421, ThinkPad i1422, ThinkPad i1441 , ThinkPad i1442, ThinkPad i1460, ThinkPad i1480, ThinkPad i1482 ThinkPad i1483, ThinkPad i1492, ThinkPad i1500, ThinkPad i1540, ThinkPad i1541, ThinkPad i1542, ThinkPad i1560, ThinkPad i1562 , ThinkPad i1592, ThinkPad i1700, ThinkPad i1720, ThinkPad i1721 , ThinkPad i1800, ThinkPad R30, ThinkPad R31, ThinkPad R32, ThinkPad R33, ThinkPad R40, ThinkPad R40e, ThinkPad R50, ThinkPad R50e , ThinkPadR51, ThinkPadS31, ThinkPad T20, ThinkPad T21, ThinkPad R52, ThinkPad T22, ThinkPad T23, ThinkPad T24, ThinkPad T30, ThinkPad S30, ThinkPad T40, ThinkPad T41, ThinkPad T41P , Thinkpad T42, ThinkPad T42P, ThinkPad T43, ThinkPad X20 , ThinkPad X21, ThinkPad X22, ThinkPad X23, ThinkPad X24, Thinkpad X30, ThinkPad X31, ThinkPad X40, ThinkPad X41

4. 19V 5.5*2.5 ACER

Compatible with laptop models:

HP Mini 1000 PC Series: 1000, 1010NR, 1030NR, 1033CL, 1035NR, FN819AV, FQ729AAR, FQ729AV, FR832AV, FT313UAR, FT313UA, FT315UAR, FT315UA, FW376UAR, FW376UA, FY348LA, FZ978UAR, FZ978UA, NB914AV, NC953AS, NC954AS, NE570PA, NE571PA, NE572PA, NE573PA, NE574PA, NE575PA, NE576PA, NE577PA, NE578PA, NE579PA, NE580PA, NE581PA, NE582PA, NE585PA, NE590PA, NE594PA, NG837LA, NJ209LA, NQ332LA

HP Mini 1000 Vivienne Tam Edition PC Series: NG624EA, NG625EA, NG626EA, NG627EA, NG628EA, NG630EA, NG631EA, NG632EA, NG633EA, NG634EA, NG640EA, NG641EA, NG644EA, NG646EA, NL037PA

HP Mini 1100 PC Series: 1110NR, 1111NR, 1120NR, 1125NR, 1130NR, 1136NR, 1141NR
NB133UAR, NB133UA, NB135UAR, NB135UA, NB137UAR, NB137UA, NB140UA, NB141UA,
NB142UAR, NB142UA, NP994UAR, NP994UA

HP Mini 1100 Vivienne Tam Edition PC Series: 1140NR Vivienne Tam, NB134UAR, NB134UA

Compatible Part Number:

496813-001, NA374AA#ABA, PPP018H,

A000001200 / A000001210 / A000007020 / A000007030 / ACC10 / ADP-65DB / ADP-65HB /
ADP-75FB-A / ADT-W61 / API1AD43 / K000000550 / K000004120 / K000005050 /
K000019570 / K000025320 / K000027270 / K000029300 / K000032420 / K000032580 /
K000040250 / K000040270 / K000040290 / K000040460 / K000041670 / K000042840 /
K000043680 / PA-1500-02 / PA-1600-01 / PA-1600-02 / PA-1650-01 / PA-1650-02 /
PA-1700-02 / PA-1750-01 / PA-1750-04 / PA3165U-1ACA / PA3380E-1ACA / PA3380U-1ACA
/ PA3396E-1ACA / PA3396U-1ACA / PA3432E-1AC3 / PA3432E-1ACA / PA3432U-1AC3 /
PA3432U-1ACA / PA3467 / PA3467E / PA3467E-1ACA / PA3467U / PA3467U-1ACA /
PA3468E / PA3468E-1ACA / PA3468U / PA3468U-1ACA / SADP-65KB / SADP-65KBB /
V000055210 / V000055400 / V000061300 / V000061310 / V000061690

Compatible Models

ACER

ACER TravelMate and Aspire Notebooks: TM211T, 212T, 213TX, TM340T, TM 341T, TM342,
TM345T, TM347T, TM351TE, TM350TE, TM352TE, TM352TE-N, TM353TE, TM353TEV,
TM354TE, TM354TEV, TM521TE, TM524TXV, TM525TE, TM525TXV, TM528TE, TM551XV,
TM600TER, TM602TER, TM603TER, TM604TER, TM 610TXV, TM610TXVi, TM610TXC,
TM611TXV, TM611TXC, TM612TXV, TM612TXC, TM613TXV, TM613TXC, TM730TX,
TM732TX, TM734TL, TM735TLV, TM738TLV, TM739TLV, 1680(1681LCi, 1681WLCi,
1681WLMi, 1683WLMi, 1684WLMi, 1685WLMi), 2010, 2020, 3502WLC, 3502WLCI,
3502WLMi, 3603WXCi, 3603WXM, 3602NWXMi, 3603WXCi 3603WXM, 3603NWXMi,
3603XCi, 3608NWXCi, 3608WXCi 3608WXM, 5002LMi, 5002WLMi, 5004WLMi
Acer Aspire: 1200, 1410 (1414WLCi), 1640 (1642WLMi), 1650, 1690 (AS1690LCi,
AS1690WLCi, AS1690WLMi, AS1691WLCi, AS1691WLMi, AS1692WLMi, AS1694WLMi),
3000 (3002LCi, 3002WLCi, 3002WLMi, 3003WCi, 3003WLCi), 3030, 3500 (3502LCi,
3502NLCi, 3503LCi, 3503WLCi, ZL6), 3600 (3603NWXMi), 3610, 5002LM, 5002LMi,
5002WLCI, 5030, 5510, 9100

Acer TravelMate: 2350, 2400, 2410, 3000 , (3002WTCi), 3210 (3213WXCi, 3213WXMi), 3220 (3220WXCi 3220WXMi, 3222WXCi, 3222WXMi), 3230, 4020, 4050 (4052LCi), 4060, 4100 (4100LCi, 4100LMi), 4150, 8100 (8104WLMi, ZF1), 2300, 2700, 290, 290E, 3200, 4000, 4500, 6000, 8000

Acer TravelMate 200 Series: 200DX, 200T, 201, 201T, 202, 202T, 210, 210T, 210TER, 210TXF, 211, 211T, 212, 212T, 212TE, 212TXV, 213, 213T, 213TXV, 222X, 223X, 223XC, 223XV, 225X, 225XC, 225XV, 230XC, 230XV, 230XV-PRO, 233LC, 233X, 233XV, 233XVi, 234LCi , 261XC, 261XV, 260, 261, 261X, 261XC, 261XV, 270XV, 272LC, 272X, 272XV, 272XVi, 273X, 273XV, 275LC, 281XC, 281XV, 283LC, 283LCi, 283XV, 283Xvi, 290LC, 290LCi, 290LMi, 290XCi, 290Xi, 290XMi, 290XVi, 291LCi, 291LCi-G, 291LMi, 291LMi-G, 291XCi, 291XCiH, 292LC, 292LCi, 292LM, 292LMi, 293LCi, 293LMi

Acer TravelMate 300 Series: 310, 311, 312, 313, 314, 310T, 311T, 312T, 313T, 314T, 320, 330T, 332T, 333T, 341TV, 342T, 343TV, 345, 347, 345T, 347T , 350TE, 350TE-N, 351TE, 351TEV, 352TE, 353TE, 353TEV, 354TE, 354TEV, 361EVi, 364ECi, 365, 371LCi, 371LMi, 371TCi, 371TCi XP, 371Ti, 371Tmi, 371LCi, 371LMi, 371TCi, 371TCi XP, 371Ti, 371Tmi

Acer TravelMate 500 Series: 512DX, 512T, 512TE, 512T-64, 513DX, 513T, 514T, 514TXV, 515TE, 516TE, 517TE, 530LC, 530LCi, 530XC, 530XCi, 530XV, 530XVi, 531LC, 531LCi, 531XC, 531XCi, 531XV, 531XVi, 533LC, 533LCi, 533XC, 533XCi, 533XV, 533XVi, 534LC, 534LCi, 534TL, 534XC, 534XCi, 534XV, 535LC, 535LCi, 536LCi , 540LCi, 540LMi, 541LC, 541LCi, 541LCib, 541LMi, 541XCi, 541XV, 542LCi, 542LMi, 543LCi, 543LMi

Acer TravelMate 600 to 663 Series: 600, 602, 603, 604, 610, 611, 612, 613, 614, 610TXC, 610TXV, 610TXVi, 611TXC, 611TXCi, 611TXV, 612TXC, 612TXCi, 612TXV, 613TXC, 613TXV, 614TXVCi, 620, 621, 623, 621LV, 621XC, 621XV, 623LC, 623LCi, 630, 632, 633, 630XV, 630XCi, 632XCi, 633LCi, 650LC, 650XC, 650XCi, 653LC, 653LCi, 653XC, 653XCi, 653XV, 654LC, 654LCi, 654XC, 654XCi, 654XV, 655LCi, 660LCi, 660LMi, 661LC, 661LCi, 661LM, 661LMi, 661XC, 661XCi, 661XVi, 662LC, 662LCi, 662LM, 662LMi, 662XCi, 663LCi, 663LM, 663LMi

Acer TravelMate 720 to 740 Series: 720, 722, 723, 720TX, 720TXV, 721TX, 722iTX, 722iTXV, 722TX, 723TX, 723TXV, 730, 732, 734, 735, 730TX, 730TXV, 732TLV, 732TX, 732TXV, 734TL, 734TXV, 735TLV, 736, 737, 738, 739, 736TL, 736TLV, 737TLV, 738TLV, 739GTLV, 739TLV, 740, 741, 744, 740LVF, 741LVF, 744LCF

Acer TravelMate 800 Series: 800LC, 800LCi, 800LCib, 800LMi, 800LMib, 800XC, 800XCi, 801LC, 801LCi, 801LCib, 801LMi, 801LMib, 801XC, 801XCi, 801XVi, 802LCi, 802LCiB,

802LMi, 802LMib, 802XCi, 803LC, 803LCi, 803LCib, 803LM, 803LMi, 803LMib, 803XCi,
803XVi, 804LC, 804LCi, 804LCib, 804LM, 804LMi, 804LMib

Asus Laptop:

Asus A6 Series: A6, A6JA, A6JC, A6Jm, A6K, A6KM, A6KT, A6M, A6T, A6Ta, A6Tc, A6R,
A6VA, A6VM

Asus A7 Series: A7C, A7D, A7F, A7G, A7J, A7Jc, A7M, A7S, A7Tc, A7V, A7Vc

Asus A8 Series: A8F, A8Jc, A8Jp, A8Jr, A8Js, A8M, A8Sc

Asus F2 Series: F2J, F2Je

Asus F3 Series: F3Ja, F3Jc, F3Jm, F3Jp, F3Jr, F3M, F3P, F3Sc, F3T, F3Tc

Asus F9 Series: F9F, F9J

Asus G Series: G1, G1S, G2, G2S

Asus M2 Series: M2000, M2000N

ASUS M3 series: M3NP

Asus M6 Series: M6000N, M6700N, M6800N, M6B00N, M6N, M6V, M6VA, M6BN

Asus W2 Series: W2J, W2Pc, W2V

Asus W3 Series: W3N, W3V

Asus W5 Series: W5A, W5F, W5V

Asus U5 Series: U5A, U5F

Asus V1 Series: V1J, V1Jp

Fujitsu Siemens Amilo A Series

A1600, A1640, A1645, A1645G, A1650, A1650G, A1667, A1667G, A1840, A2200+, A6600,
A6660, A7600, A7620, A7640, A7645, A8600, A8620, A8625,

Fujitsu Siemens Amilo L Series

L1300, L1300G, L1310G, L6810, L6820, L6825, L7300, L7310, L7320,

Fujitsu Siemens Amilo M Series: M1425, M7405,

Fujitsu Siemens Amilo Pro V1 Series: V1000,

Fujitsu Siemens Amilo Pro V2 Series: V2000, V2010, V2020, V2030, V2035, V2040, V2045,
V2055, V2060, V2065, V2085

Fujitsu Siemens Amilo Pro V3 Series: V3205, V3405, V3505, V3515, V3525, V3545,

Fujitsu Siemens Amilo Pro V7 Series: V7010

Fujitsu Siemens Amilo Pro V8 Series: V8010, V8210

Fujitsu Siemens Celcius H Series: H210, H230, H240

Fujitsu Siemens Celcius Mobile series: Mobile, Mobile 2, Mobile A, Mobile H, Mobile S

Fujitsu Siemens LifeBook C1000 Series: C1010, C1020, C1110, C1110D, C1211, C1211D, C1212, C1212D, C1320, C1320D, C1321, C1410

Fujitsu Siemens LifeBook C2000 Series: C2000, C2010, C2032, C2100, C2110, C2111, C2210, C2220, C2230, C2240, C2310, C2320, C2330, C2340,

Fujitsu Siemens LifeBook C6000 Series: C6632, C6659, C6661

Fujitsu Siemens LifeBook E2000 series: E2000, E2010,

Fujitsu Siemens LifeBook E4000 series: E4000D, E4010, E4010D,

Fujitsu Siemens LifeBook E6000 Series: E6180, E6624, E6634, E6644, E6646, E6654, E6664

Fujitsu Siemens LifeBook E7000 Series: E7010, E7110

Fujitsu Siemens LifeBook E8000 Series: E8010, E8020, E8020D, E8110

Fujitsu Lifebook N Series: N3511, N3520, N3530, N6110, N6210, N6410, N6420

Fujitsu Lifebook S Series: S2210, S6310, S6311, S6410, S7010, S7010D, S7020, S7020B, S7020D, S7020E, S7021, S7025, S7110, S7111

Fujitsu Lifebook T Series: T4020A, T4020B, T4020D

5. 18.5V 4.8*1.7 HP

Compatible with laptop models:

HP PAVILION / COMPAQ PRESARIO:

HP/COMPAQ 710C HP/COMPAQ 712C

HP/COMPAQ 720C HP/COMPAQ 722C

HP/COMPAQ 810C HP/COMPAQ 812C

HP/COMPAQ 815C HP/COMPAQ 820

HP/COMPAQ 820CSE HP/COMPAQ 820

HP/COMPAQ 825C HP/COMPAQ 830C

HP/COMPAQ 832C HP/COMPAQ 840C

HP/COMPAQ 841C HP/COMPAQ 842C

HP/COMPAQ 843C HP/COMPAQ 845C

HP/COMPAQ850C HP/COMPAQ855C

HP/COMPAQ 855CSE HP/COMPAQ 855CXI

HP/COMPAQ 870CSE HP/COMPAQ 870CSI

HP/COMPAQ 880C HP/COMPAQ 882C

HP/COMPAQ 890CSE HP/COMPAQ 890CSI

HP/COMPAQ 895CSE HP/COMPAQ 895CSI
HP/COMPAQ 920C HP/COMPAQ 960C HP/COMPAQ 960CXI

HP Compaq Tablet PC: tc1000, tc1100, tc4200

HP Compaq Business Notebook: nc4000, nc4010, nc6000, nc8000, nx5000, nx6100, nw8000

HP Pavilion DV1000 Series: DV1000 / DV1000 CTO / DV1001 / DV1001AP / DV1001XX MV IUR / DV1002 / DV1002AP / DV1002XX MV IUR / DV1003 / DV1004 / DV1004AP / DV1005 / DV1006 / DV1006AP / DV1007 / DV1008 / DV1009 / DV1009AP / DV1009XX MV / DV1010 / DV1010AP / DV1010US / DV1010CA / DV1011 / DV1011 / DV1012 / DV1012LA / DV1013 / DV1014 / DV1014AP / DV1014LA / DV1015 / DV1015AP / DV1015LA / DV1016 / DV1017 / DV1018 / DV1019 / DV1020 / DV1021 / DV1021AP / DV1022 / DV1022AP / DV1023 / DV1024 / DV1024AP / DV1024LA / DV1025 / DV1025AP / DV1025LA / DV1026 / DV1027 / DV1028 / DV1029 / DV1029AP / DV1030 / DV1030AP / DV1031 / DV1031AP / DV1032 / DV1033 / DV1034 / DV1034AP / DV1040 / DV1040US / DV1040CA / DV1042 / DV1044 / DV1045 / DV1045LA / DV1049 / DV1049CL / DV1050 / DV1050US / DV1060 / DV1060US / DV1061 / DV1063 / DV1064 / DV1065 / DV1065US /

HP Pavilion DV1300 Series: DV1300 / DV1310 / DV1310US / DV1311 / DV1311SE / DV1315 / DV1315CL / DV1320 / DV1320US / DV1321us / DV1330 / DV1330CA / DV1330US / DV1340 / DV1340US

HP Pavilion DV1400 Series: DV1400 / DV1410 / DV1410US / DV1411 / DV1411SE / DV1420 / DV1420US / DV1427us / DV1430 / DV1430US / DV1432 / DV1432US / DV1435 / DV1439 / DV1439US / DV1440 / DV1440US

HP Pavilion DV1500 Series: DV1500 / DV1510 / DV1510US / DV1510CA / DV1515 / DV1515CL / DV1519 / DV1519US / DV1520 / DV1520US / DV1520CA / DV1530 / 1530US / DV1530CA / DV1532 / DV1532US / DV1540 / DV1540US / DV1540CA / DV1550 / DV1550SE / DV1580 / DV1580SE

HP Pavilion DV2000 series dv2000 , dv2000t, dv2000z, dv2001tu, dv2001tx, dv2001xx, dv2002tu, dv2002tx, dv2002xx, dv2003ea, dv2003tu, dv2003tx, dv2004ea, dv2004tu, dv2004tx, dv2004xx, dv2005ea, dv2005tu, dv2005tx, dv2005xx, dv2006ea, dv2006tu, dv2006tx, dv2006xx, dv2007ea, dv2007tu, dv2007tx, dv2008ea, dv2008tu, dv2008tx, dv2009ea, dv2009tu, dv2009tx, dv2009xx, dv2010ea, dv2010tu, dv2010tx, dv2011ea, dv2011tu, dv2011tx, dv2012ea, dv2012tu, dv2012tx, dv2013ea, dv2013tu, dv2013tx, dv2014ea, dv2014tu, dv2014tx, dv2015ea, dv2015nr, dv2015tu, dv2015tx, dv2016ea, dv2016tu, dv2016tx, dv2017ea, dv2017tu, dv2017tx, dv2018ea, dv2018tu, dv2018tx, dv2019ea, dv2019tu, dv2019tx, dv2020ca, dv2020ea, dv2020tu, dv2020tx, dv2020us, dv2021tu, dv2021tx, dv2022tu, dv2023tu, dv2024tu, dv2024tx, dv2025la, dv2025nr, dv2025tu, dv2025tx,

dv2026tu, dv2026tx, dv2027tu, dv2027tx, dv2028ea, dv2028tu, dv2028tx, dv2029ea,
dv2029tu, dv2029tx, dv2030ea, dv2030tu, dv2030tx, dv2031ea,
dv2031tu, dv2031tx, dv2032ea, dv2032tu, dv2032tx, dv2033ea, dv2033tu, dv2033tx,
dv2034ea, dv2034tu, dv2034tx, dv2035ea, dv2035la, dv2035tu,
dv2035tx, dv2035us, dv2036ea, dv2036tu, dv2036tx, dv2037tu, dv2037tx, dv2037us,
dv2038tu, dv2038tx, dv2039tu, dv2039tx, dv2040ca, dv2040tu,
dv2040tx, dv2040us, dv2041tu, dv2041tx, dv2042tu, dv2042tx, dv2043tu, dv2043tx, dv2044tu,
dv2044tx, dv2045ea, dv2045tu, dv2046tu, dv2046tx,
dv2047cl, dv2047tx, dv2048tx, dv2049tx, dv2050tx, dv2050us, dv2053ea, dv2054ea,
dv2055ea, dv2056ea, dv2057ea, dv2058ea, dv2064ea, dv2065ea, dv2080ea, dv2081ea,
dv2082ea, dv2083ea, dv2084ea, dv2085ea, dv2088xx, dv2095ea, dv2097ea, dv2098ea,
dv2099ea, dv2100, dv2101au, dv2101eu, dv2101tu, dv2101tx, dv2101xx, dv2102au, dv2102eu,
dv2102tu, dv2102tx, dv2103au, dv2103ea, dv2103tu, dv2103tx, dv2104au, dv2104ea,
dv2104eu, dv2104tu, dv2104tx, dv2105ea, dv2105tu, dv2105tx, dv2106ea,
dv2106eu, dv2106tu, dv2106tx, dv2107tu, dv2107tx, dv2108ea, dv2108tu, dv2108tx, dv2109tu,
dv2109tx, dv2110eu, dv2110tu, dv2110tx, dv2111tu, dv2111tx, dv2112tu, dv2112tx, dv2113tu,
dv2113tx, dv2114tx, dv2115ea, dv2115tu, dv2115tx, dv2116ea, dv2116tx, dv2116wm,
dv2117tx, dv2118la, dv2118tx, dv2119tx, dv2120ca, dv2120la, dv2120tu, dv2120tx, dv2120us,
dv2121tu, dv2121tx, dv2122tu, dv2122tx, dv2123tu, dv2123tx, dv2124tx, dv2125la, dv2125nr,
dv2125tx, dv2126tx, dv2127tx, dv2128tx, dv2129ea, dv2129tx, dv2130br, dv2130ea, dv2130tx,
dv2130us, dv2131ea, dv2131tx, dv2132ea, dv2132tx, dv2133ea, dv2133tx, dv2134ea,
dv2134tx, dv2135la, dv2135tx, dv2136tx, dv2137tx, dv2138tx, dv2138xx, dv2139tx, dv2140br,
dv2140eu, dv2140tx, dv2141eu, dv2141tx, dv2142tx, dv2143tx, dv2144tx, dv2145tx, dv2146tx,
dv2147ea, dv2147tx, dv2148tx, dv2149ea, dv2149tx, dv2150ea, dv2150tx, dv2151ea,
dv2151tx, dv2152ea, dv2152tx, dv2153tx, dv2154tx, dv2155tx, dv2160br, dv2164eu,
dv2166eu, dv2171ca, dv2171cl, dv2171ea, dv2172ea, dv2173ea, dv2174cl, dv2174ea,
dv2175ea, dv2180eu, dv2184ea, dv2185ea, dv2188ea, dv2190ea, dv2195eu, dv2196ea,
dv2197ea, dv2200, dv2210us

HP Pavilion DV2500 Series dv2500, dv2500t, dv2501tu, dv2501tx, dv2501xx, dv2502tu,
dv2502tx, dv2503tu, dv2503tx, dv2503xx,
dv2504tu, dv2504tx, dv2505tu, dv2505tx, dv2506tu, dv2506tx, dv2506xx, dv2507tu, dv2507tx,
dv2508tu, dv2508tx, dv2509tu, dv2509tx, dv2510tu,
dv2510tx, dv2511tu, dv2511tx, dv2512tu, dv2512tx, dv2513tu, dv2513tx, dv2514tu, dv2514tx,
dv2515ea, dv2515tu, dv2515tx, dv2516tu, dv2516tx,
dv2517tu, dv2517tx, dv2518tu, dv2518tx, dv2519ea, dv2519tu, dv2519tx, dv2520ea,
dv2520tu, dv2520tx, dv2521ea, dv2521tx, dv2522tx, dv2523tx,
dv2524tx, dv2525ea, dv2527tx, dv2528ea, dv2528tx, dv2529ea, dv2529tx, dv2530ea,
dv2530tx, dv2534tx, dv2535la, dv2535tx, dv2536tx, dv2550se,
dv2554ea, dv2555ea, dv2560ea

HP Pavilion DV4000 Series: DV4000 / DV4000 CTO / DV4005 / DV4005US / DV4010 /
DV4015 / DV4015CL / DV4018 / DV4018CL / DV4020 / DV4020us / DV4030 / DV4030US /
DV4030CA / DV4040 / DV4040CA / DV4040US / DV4100 / DV4100 CTO / DV4125 /
DV4125US / DV4129 / DV4129US / DV4130 / DV4130US / DV4150 / DV4150CA / DV4150US

/ DV4155 / DV4155CL / DV4155US / DV4165 / DV4165CL / DV4170 / DV4170CA /
DV4170US / DV4200 / DV4210 / DV4217 / DV4217CL / DV4220 / DV4223 / DV4223CL /
DV4230 / DV4230us / DV4250 / DV4250US / DV4250CA / DV4253 / DV4253US / DV4257 /
DV4257US / DV4269 / DV4269US / DV4270 / DV4270US / DV4270CA / DV4272 / DV4272US
/ DV4300 / DV4305 / DV4305US / DV4307 / DV4307CA / DV4307CL / DV4308 / DV4308WM /
DV4310 / DV4310US / DV4320 / DV4320US / DV4330 / DV4330US / DV4330CA / DV4340 /
DV4340US / DV4340CA / DV4400 / DV4401 / DV4420

HP Pavilion DV5000 Series: DV5000 / DV5001 / DV5003 / DV5003CL / DV5010 / DV5017 /
DV5017CL / DV5020 / DV5020US / DV5020CA / DV5029 / DV5029US / DV5030 / DV5030US
/ DV5040 / DV5040US / DV5100 / DV5100CTO / DV5110 / DV5110US / DV5120 / DV5120US
/ DV5123 / DV5123CL

HP Pavilion DV6000 Series

HP Pavilion DV8000 Series: DV8000 / DV8000 CTO / DV8005 / DV8010 / DV8013 /
DV8013CL / DV8026ea / DV8040 / DV8040CA / DV8040US / DV8045 / DV8080 / DV8088 /
DV8088US / DV8100 / DV8110 / DV8110US / DV8113 / DV8113CL / DV8120 / DV8120US /
DV8120CA / DV8123 / DV8123CL / DV8125 / DV8125NR / DV8130 / DV8130US / DV8135nr /
DV8140 / DV8140US / DV8155 / DV8200 / DV8220 Series

HP Pavilion ZT3000 Series: HP Pavilion ZT3000 / ZT3001 / ZT3001US / ZT3010 / ZT3010US /
ZT3015 / ZT3020 / ZT3020US / ZT3025 / ZT3030 / ZT3040 / ZT3050 / ZT3068 / ZT3068CL /
ZT3101 / ZT3101US / ZT3110 / ZT3120 / ZT3130 / ZT3140 / ZT3140US / ZT3170 / ZT3170US
/ ZT3200 / ZT3201 / ZT3201US / ZT3205 / ZT3210 / ZT3215 / ZT3220 / ZT3225 / ZT3230 /
ZT3235 / ZT3240 / ZT3241 / ZT3242 / ZT3250 / ZT3250US / ZT3260 / ZT3280 / ZT3280US /
ZT3300 / ZT3301 / ZT3301US / ZT3302 / ZT3302US / ZT3305 / ZT3310 / ZT3340 / ZT3340US
/ ZT3349 / ZT3349CL / ZT3350 / ZT3350US / ZT3355 / ZT3355US / ZT3380 / ZT3380US /
ZT3400

HP Pavilion ZE2000 Series: HP Pavilion ZE2000 / ZE2000 CTO / ZE2004 / ZE2004US /
ZE2005 / ZE2005US / ZE2008 / ZE2008WM / ZE2010 / ZE2015 / ZE2015US / ZE2020 /
ZE2020CA / ZE2100 / ZE2108 / ZE2108WM / ZE2109 / ZE2109US / ZE2110 / ZE2110US /
ZE2113 / ZE2113US / ZE2114 / ZE2114US / ZE2115 / ZE2115US / ZE2117 / ZE2117US /
ZE2120 / ZE2120CA / ZE2150 / ZE2150US / ZE2200 / ZE2200 CTO / ZE2300 / ZE2308 /
ZE2308WM / ZE2309 / ZE2309NR / ZE2315 / ZE2315US / ZE2400 / ZE2401 / ZE2401XT

HP Pavilion ZE4900 Series: ZE4900 / ZE4901 / ZE4901us / ZE4902 / ZE4903 / ZE4904 /
ZE4905 / ZE4906 / ZE4907 / ZE4908 / ZE4910 / ZE4910us / ZE4911 / ZE4913 / ZE4915 /
ZE4916 / ZE4917 / ZE4918 / ZE4919 / ZE4920 / ZE4922 / ZE4923 / ZE4925 / ZE4926 /
ZE4928 / ZE4929 / ZE4930 / ZE4935 / ZE4940 / ZE4950 / ZE4951 / ZE4960 / ZE4980

Compaq Presario M2000 Series: M2000 / M2001 / M2005 / M2005US / M2007 / M2007US /
M2010 / M2010CA / M2010US / M2015 / M2015CL / M2070 / M2070US / M2099 / M2100 /

M2100 / M2101 / M2101US / M2105 / M2105CA / M2105US / M2108 / M2108US / M2200 / M2300 / M2400 / M2401 / M2401XT

Compaq Presario 2200 Series: 2200 / 2200LA / 2201 / 2201AS / 2201US / 2202 / 2202US / 2203 / 2203AL / 2203AS / 2203US / 2204 / 2204AL / 2204AS / 2204US / 2205 / 2205AL / 2205AP / 2205AS / 2205LA / 2206 / 2206AL / 2206AP / 2206US / 2207 / 2207AL / 2207AP / 2207AS / 2208 / 2208AP / 2208AS / 2209 / 2209AP / 2209CL / 2210 / 2210AP / 2210CA / 2210US / 2211 / 2211AP / 2212CA / 2213 / 2214 / 2215 / 2216 / 2217 / 2218 / 2218AP / 2218RS / 2219 / 2220,2223 / 2223AP / 2223US / 2226 / 2226AP / 2226CL / 2227 / 2227AP / 2227US / 2231 / 2231AP / 2231US / 2232 / 2232AP / 2232US / 2233AP / 2234AP / 2236 / 2236AP / 2236CL / 2236US / 2237AP / 2238AP / 2242AP / 2243AP / 2254 / 2255 / 2256 / 2257 / 2258 / 2258AP / 2259 / 2260 / 2261 / 2261AP / 2262 / 2262AP / 2263 / 2263AP / 2265 / 2268AP / 2269AP / 2273AS

Compaq Presario 2800 Series: 2800 / 2800CA / 2800T / 2800US / 2801 / 2801CL / 2805 / 2805US / 2806 / 2806CL / 2810 / 2810CA / 2810EA / 2811 / 2811CA / 2811CL / 2811EA / 2815 / 2815EA / 2816 / 2816EA / 2878 / 2878CL / 2879 / 2879CL / 2880 / 2880CL / 2881 / 2881CL

Compaq Presario V2000 Series: V2000 / V2000t / V2000z / V2001 / V2002 / V2003 / V2004 / V2005 / V2006 / V2007 / V2008 / V2009 / V2010 / V2010US / V2016 / V2017 / V2018 / V2019 / V2020 / V2021 / V2022 / V2023 / V2024 / V2025 / V2026 / V2027 / V2028 / V2029 / V2030 / V2030US / V2031 / V2032 / V2033 / V2034 / V2035 / V2036 / V2037 / V2038 / V2039 / V2040 / V2040US / V2041 / V2069 / V2069CL

Compaq Presario V2100 Series: V2100 / V2110 / V2110US / V2110CA / V2130 / V2135 / V2135US / V2140 / V2140US / V2140CA / V2146 / V2146CL / V2150 / V2150US

Compaq Presario V2300 Series: V2300 / V2304 / V2304US / V2305 / V2305CA / V2305US / V2306 / V2306US / V2309 / V2309US / V2310 / V2310CA / V2310US / V2311 / V2311US / V2312 / V2312US / V2320 / V2321 / V2321US / V2330 / V2335 / V2335US

Compaq Presario V2400 Series: V2400 / V2400 CTO / V2401 / V2401CL / V2402 / V2402US / V2403 / V2403NR / V2403us / V2404 / V2404US / V2405 / V2405CA / V2405US / V2409 / V2409US / V2410 / V2410CA / V2410CL / V2410US / V2413 / V2413US / V2414 / V2414NR / V2419 / V2419US / V2424 / V2424NR

Compaq Presario V2500 Series: V2500 / V2508 / V2508WM / V2552 / V2552US / V2555 / V2555US / V2555CA / V2565 / V2565US / V2565CA / V2570 / V2570CA / V2570NR / V2575 / V2575US / V2575CA / V2582 / V2582US

Compaq Presario V2600 Series: V2600 / V2610 / V2610US / V2630 / V2630US / V2640 / V2640NR / V2665 / V2665US / V2698 / V2699

Compaq Presario V4000 Series: V4000 / V4000z / V4001 / V4002 / V4003 / V4004 / V4005 / V4005CL / V4015 / V4015US / V4020 / V4020US / V4025 / V4025US / V4035 / V4035CA / V4035US / V4100 / V4120 / V4120US / V4125 / V4125CL / V4130 / V4135 / V4135US / V4200 / V4220 / V4220NR / V4220US / V4240 / V4240US / V4245 / V4245US / V4300 / V4400

Compaq Presario V5000 Series: V5000 / V5000Z / V5005 / V5005US / V5005CA / V5010 / V5015 / V5015US / V5015CA / V5100 CTO / V5100z CTO / V5101 / V5101US / V5102 / V5102NR / V5105 / V5105US / V5105CA / V5115 / V5115US / V5115CA / V5119 / V5119US / V5120 / V5120NR / V5160 / V5160US / V5189 / V5200 CTO / V5201 / V5201US / V5201CA / V5204 / V5204US / V5204NR / V5205 / V5205NR / V5206 / V5206OM / V5207 / V5207NR / V5208 / V5208CA / V5209 / V5209US / V5210 / V5210US / V5210CA / V5214EA / V5215EA / V5216EA / V5233EA / V5234EA / V5235EA / V5236EA / V5300 CTO / V5305 / V5305WM / V5306 / V5306US / V5307 / V5307US / V5308 / V5308CA

Compaq Presario V6000 Series: V6000 V6000T V6000Z V6001XX V6030US V6048CL V6101 / V6101US / V6105 / V6105NR / V6107 / V6107US / V6110 / V6110US / V6110CA / V6120 / V6120US / V6120CA / V6130 / V6130US / V6133 / V6133CA / V6133CL / V6137 / V6137US / V6143 / V6143CL / V6171 / V6171CL

Compaq Armada Series: 100 / 100s / 110 / 110s / E300 / E500 / E500s / E700 / M300 / M500 / M700 / V300 / N400c / N410c / N600c

Compaq EVO Series: EVO N1000 / N1000C N1000V / N1005V / N110 / N150 / N200 / N400 / N400c / N410c / N600 / N600c / N610c / N620c / N800 / N800c / N800v / N800w / N8000

Compaq Presario X1000 Series: X1000 / X1001 / X1001US / X1002 / X1002US / X1005 / X1006 / X1007 / X1010 / X1010CA / X1010US / X1011 / X1012 / X1015 / X1015US / X1016 / X1018 / X1021 / X1022 / X1023 / X1026 / X1027 / X1028 / X1028CL / X1030 / X1030US / X1032 / X1033 / X1034 / X1035 / X1036 / X1036AP / X1037 / X1038 / X1039 / X1040 / X1040US / X1041 / X1042 / X1043 / X1044 / X1045 / X1046 / X1047 / X1048 / X1049 / X1050 / X1050CA / X1051 / X1052 / X1053 / X1054 / X1055 / X1056 / X1057 / X1058 / X1060 / X1061 / X1062 / X1063 / X1064 / X1065 / X1066 / X1067 / X1068 / X1069 / X1070 / X1071 / X1072 / X1073 / X1074 / X1075 / X1080 / X1081 / X1082 / X1083 / X1084 / X1085 / X1086 / X1087 / X1088 / X1089 / X1090 / X1091 / X1092 / X1093 / X1094 / X1095 / X1096 / X1097 / X1098 / X1099

Compaq Presario X1100 Series: X1100 / X1105 / X1110 / X1115 / X1140 / X1155

Compaq Presario X1200 Series: X1200 / X1201 / X1201US / X1210 / X1210CA / X1210US / X1220 / X1220US / X1230 / X1230US

Compaq Presario X1300 Series: X1300 / X1301 / X1301US / X1360 / X1360US / X1360CL / X1360CA / X1370 / 1370US / X1390 / X1390US / X1937 / X1397US

6. 15V 6.3*3.0 TOSHIBA

- **Compatible TOSHIBA Part numbers:**

PA2450U, PA3241U-1ACA, PA3049U-1ACA, PA3153U-1ACA, PA3241U-2ACA, PA3080U-1ACA
PA2409U, PA2411, PA2411U, PA2426U, PA2438, PA2438U, PA2440, PA2440U, PA2444, PA2444U, PA2444UE, PA2450, PA2450U, PA2450UE, PA2484, PA2484U, PA2500, PA2500U, PA3048, PA3048E, PA3048U, PA3048U-1ACA, PA3049, PA3049U, PA3049U-1ACA, PA3080, PA3080E, PA3080E-1ACA, PA3080U, PA3080U-1ACA, PA3084, PA3084U, PA3084U-1ACA, PA3092U, PA3092U-1ACA, PA3153, PA3153E, PA3153E-1ACA, PA3153E-1ACAB, PA3153U, PA3153U-1ACA, PA3201, PA3201U, PA3201U-1ACA, PA3241, PA3241E, PA3241E-1ACA, PA3241E-1ACAB, PA3241E-2ACA, PA3241U, PA3241U-1ACA, PA3241U-2ACA, PA3260E, PA3260E-1ACA, PA3260U, PA3260U-1ACA, PA3282, PA3282E, PA3282E-1ACA, PA3282E-2ACA, PA3282U, PA3282U-1ACA, PA3282U-2ACA, PA5251U, PA5251UA, PA3378U-1ACA, PA3378U, PA3378E-1ACA, PA3378E, PA3283U, PA3283U-1ACA, PA3283U-2ACA, PA3283U-3ACA, PA3283U-4ACA, PA3283U-5ACA, PA3083U, PA3083U-1ACA, PA3292U-1ACA, PA2301U-1ACA, PA3201U, PA3201-1ACA, PA3215U, PA3215U-1ACA, G71C0002S310, G71C0002S110, ADP-60RHA, PA2450U
Compatible with Toshiba follows:

Toshiba Dynapad: T200, T200CS

Toshiba Libretto: 50CT, 70CT

Toshiba Portege:

M100, 7000CT, 7010CT, 7015CT, 7020CT, 7140CT, 7200CT, 7200CTE, 7220CTE

Toshiba Satellite:

4000, 1500, 1555, 1555CDS, 2100CDS, 2100CDT, 2105CDS, 2115, 2115CDS, 2140, 2140CDT, 2140XCDS, 2180, 2180CDT, 220CDS, 2210CDT, 2210XCDS, 2250CDT, 2250XCDS, 225CDS, 230CDS, 235, 235CDS, 250, 2500CDS, 2500CDT, 2505CDS, 2505CDT, 2510CDS, 2515CDS, 2515CDT, 2515CTS, 2520CDT, 2530CDS/4, 2535CDS/4, 2535CDT, 2540CDS/4, 2540CDT, 2545CDS/4, 2545CDT, 2590CDS/4, 2595CDS/4, 2610DVD, 2615DVD, 2710XDVD, 2770XDVD, 315CD, 4000CDS, 4000CDT, 4000SCDS/4, 4005CDS, 4005CDS/4, 4005CDT, 4010CDS, 4010CDS/4, 4010CDT, 4015CDS, 4015CDS/4, 4015CDT, 4020CDT, 4020CDT/6, 4025CDT, 4025CDT/6, 4030CDT, 4030CDT/4, 4035CDT, 4060CDT, 4060CDT/4, 4060XCDT, 4070CDS, 4070CDT, 4080XCDT, 4080XCDT/6, 4085XCDT, 4090XCDT, 4100XCDT, 4100XDVD, 4100XDVD/6, 4320ZDVD, 4340ZDVD, 4360ZDVD

Toshiba Satellite Pro: 4200, 4300, 2590CDS, 2590CDT, 2590XDVD, 2655XDVD, 2715XDVD, 2755XDVD, 4090XDVD, 4260DVD, 4260XDVD, 4270ZDVD, 4280XDVD, 440, 440CDT, 440CDX, 445CDT, 445CDX, 450CDT, 450CDX, 460CDT, 460CDX, 465CDT, 465CDX, 470, 470CDT, 480CDT, 480CDX, 485CDT, 485CDX, 490CDT, 490CDX,

490XCDT, 495CDT, 495CDX

Toshiba Tecra: 8000, 520, 520CDS, 520CDT, 530CDT, 550, 550CDT

Toshiba Satellite 200/300 Series:

220, 220CDS, 225, 225CDS, 230, 230CDS, 230CX, 235, 235CDS, 250, 300, 300CDS, 305, 305CDS, 305CDT, 310, 310CDS, 310CDT, 315, 315CD, 315CDS, 315CDT, 320, 320CDS, 320CDT, 320CT, 325, 325CDS, 325CDT, 330, 330CDS, 330CDT, 335, 335CDS, 335CDT

Toshiba Satellite 1500/2000 Series:

1500, 1555, 1555CDS, 2060CDS, 2060CDT, 2065CDS, 2065CDT, 2100, 2100CDS, 2100CDT, 2100CDX, 2105CDS, 2105CDT, 2115, 2115CDS, 2140, 2140CDT, 2140XCDS, 2180, 2180CDT, 2210CDT, 2210XCDS, 2250CDT, 2250XCDS, 2410, 2410-S203, 2410-S204, 2410-S205, 2410-S206, 2415, 2415-S205, 2450, 2455, 2455-S3001, 2455-S305, 2455-S306, 2520, 2520CDT, 2450, 2455, 2455-S3001, 2455-S305, 2455-S306, 2500CDS, 2500CDT, 2505CDS, 2505CDT, 2510CDS, 2410CDS/4, 2515CDS, 2415CDS/4, 2515CDT, 2515CTS, 2530CDS, 2530CDS/4, 2535CDS, 2535CDS/4, 2535CDT, 2540CDS, 2540CDS/4, 2540CDT, 2545CDS, 2545CDS/4, 2545CDT, 2545XCDT, 2590CDS, 2590CDS/4, 2590CDT, 2590XDVD, 2595CDS, 2595CDS/4, 2595CDS, 2595CDS/4, 2595CDT, 2595XDVD, 2610-2675, 2610DVD, 2615DVD, 2655XDVD, 2675DVD, 2715, 2715DVD, 2715XDVD, 2710XDVD, 2755DVD, 2755XDVD, 2770XDVD, 2775XDVD, 2800, 2800-S201, 2800-S202, 2800-S210, 2805, 2805-S201, 2805-S301, 2805-S302, 2805-S401, 2805-S402, 2805-S503

Toshiba Satellite 4000 Series:

4000, 4000CDS, 4000CDS/4, 4000CDT, 4000SCDS/4, 4005CDS, 4005CDS/4, 4005CDT, 4010CDS, 4010CDS/4, 4010CDT, 4015CDS, 4015CDS/4, 4015CDT, 4020, 4020CDT, 4020CDT/6, 4025CDT, 4025CDT/6, 4030CDT, 4030CDT/4, 4035CDT, 4060, 4060CDT, 4060CDT/4, 4060XCDT, 4070, 4070CDS, 4070CDT, 4080, 4080CDT, 4080XCDT, 4080XCDT/6, 4085, 4085XCDT, 4090, 4090CDS, 4090XCDT, 1090XDVD, 4090XDVD/6, 4100, 4100XCDT, 4100XDVD, 4100XDVD/6, 4200, 4260, 4260DVD, 4280, 4280XDVD, 4280ZDVD, 4300, 4320ZDVD, 4340ZDVD, 4360ZDVD, 4400, 4400CDT, M20-258, 4400, 4400CDT, M20-258, 4400, 4400CDT, M20, M20-S257

Satellite 5000 Series:

5000, 5000-104, 5000-X1Z, 5000-X59, 5000-Z59, 5005, 5005-S503, 5005-S504, 5005-S507, 5005-S508, 5100, 5100-046, 5100-201, 5100-501, 5100-503, 5100-603, 5100-A740, 5100-A741, 5100-A801, 5100-A902, 5105, 5105-S501, 5105-S-501, 5105-S502, 5105-S607, 5105-S608, 5105-S701, 5105-S702, 5105-S901, 5200, 5200-00E, 5200-701, 5200-702, 5200-703, 5200-711, 5200-801, 5200-802, 5200-803, 5200-901, 5200-902, 5200-903, 5200-P0E, 5200-S701, 5205, 5205-S119, 5205-S503, 5205-S504, 5205-S505, 5205-S506, 5205-S5151, 5205-S703, 5205-S704, 5205-S705, 5205-SP119, 5205-SP505

Toshiba Tecra:

520, 520CDS, 520CDT, 530CDS, 530CDT, 550, 550CDT, 700, 700CS, 700CT, 710CDT, 720, 720CDT, 730CDT, 730XCDT, 740, 740CDT, 750, 750CD, 750CDM, 750CDT, 750DVD, 780, 780CDM, 780CDT, 780DVD, 8000, 8200

Toshiba Portege:

650, 650CT, 660, 660CDT, 660CT, 600CT, 610, 610CT, 620, 620CT, 300CT, 305CT, 310CT, 315CT, 320CT, 325CT, 330CT, 335CT, 2000, 7000CT, 7010CT, 7015CT, 7020CT, 7140CT, 7200CT, 7200CTE, 7220CTE, T3400C, T3400CT, T3600CT

Toshiba Satellite Pro:

440, 440CDT, 440CDX, 445CDT, 445CDX, 450CDT, 450CDX, 460CDT, 460CDX, 465CDT, 465CDX, 470, 470CDT, 480CDT, 480CDX, 485CDT, 485CDX, 490CDT, 490CDX, 490XCDT, 495CDT, 495CDX, 4200, 4260DVD, 4270, 4270DVD, 4270XDVD, 4280XDVD, 4280ZDVD, 4300, 4320, 4320ZDVD, 4340, 4340ZDVD, 4360, 4360ZDVD

Toshiba:

1800, 1850, 1850C, T4500, T4500C, T4600, T4600C, 4280ZDVD

Fit Laptop Model

Satellite:

220CDS, 220CDS (16MB-base), 220CDS (32MB-base), 220CS (16MB-base), 220CS (32MB-base), 225CDS, 225CDS, 230CDS, 230CX, 300, 300CDS, 300CDT, 305, 305CDS, 305CDT, 310CDS, 310CDT, 315CDS, 315CDT, 320CDS, 320CDT, 325CDS, 330CDS, 330CDT, 335CDS, 335CDT, T1800, T1850, T1850C, 2100CDS, 2100CDT, 2105CDS, 2540CDS, 2540CDT, 2540XCDT, 2545CDS, 2545XCDT, 2590, 2590CDS, 2590CDT, 2590XDVD, 2595CDS, 2595CDT, 2595XDVD, 2615, 2615DVD, 2655, 2655XDVD, 4000, 4000CDS, 4000CDT, 4005CDS, 4005CDT, 4010CDS, 4010CDT, 4015CDS, 4015CDT, 4020CDT, 4025CDT, 4030CDS, 4030CDT, 4030CDT-NT, 4060CDT, 4060CDT-NT, 4060XCDT, 4070CDS, 4070CDT, 4080CDS, 4080CDT, 4080XCDT, 4080XCDT-NT, 4085XCDT, 4090CDS, 4090CDT, 4090XCDT, 4090XDVD, 4090XDVD-NT, 4100, 4100CDS, 4100CDT, 4100XCDT, 4100XDVD, 4100XDVD-NT

Satellite Pro:

440CDS, 440CDT, 440CDX, 445CDS, 445CDT, 445CDX, 450CDT, 450CDX, 460CDT, 460CDX, 465CDT, 465CDX, 470, 470CDT, 480CDT, 480CDX, 485CDT, 485CDX, 490CDT, 490CDT-NT, 490CDX, 490XCDT, 490XCDT-NT, 495CDT, 495CDX

Portege:

2000, 2010, 3500, 3505, 4000, 4005, 4010, 7000CT, 7000CT-NT, 7010CT, 7010CT-NT, 7020, 7020CT, 7020CT-NT, 7140CT, 7140CT-NT, 7200CT, 7200CTe, 7220CTe

Tecra

500CDS, 500CDT, 500CS, 505CDS, 505CDT, 510CDS, 510CDT, 510CS, 515CDS, 515CDT, 520CDT, 530CDS, 530CDT, 540CDT, 550, 550CDT, 700, 700CD, 700CDT, 700CS, 700CT, 710, 710CDT, 720, 720CDT, 730, 730CDT, 730XCDT, 740CDT, 740CDT-NT, 750CDM, 750CDM-NT, 750CDT, 750DVD, 780, 780CDM, 780CDM-NT, 780DMT, 780DVD, 8000, 8000-4B51, 8000-4K71, 8000-C951, 8000-KB51, 8100, 8200

7. 16V 6.4*1.0 SONY

Compatible Models:

SONY VAIO SERIES

PCG-700 , PCG-705 , PCG-707 , PCG-707C , PCG-711 , PCG-717, PCG-719 , PCG-729 , PCG-735 , PCG-748 , PCG-803 , PCG-808 , PCG-812 , PCG-818 , PCG-838 , PCG-861/BP , PCG-862 , PCG-864 , PCG-868 , PCG-881/BP , PCG-883 , PCG-883/BP , PCG-885 , PCG-887 , PCG-887/BP , PCG-887/BP2 , PCG-888...

SONY VAIO F SERIES

PCG-F150 , PCG-F180 , PCG-F190 , PCG-F250 , PCG-F270 , PCG-F280 , PCG-F290 , PCG-F340 , PCG-F350 , PCG-F350 (HITACHI LCD) , PCG-F350 (SAMSUNG LCD) , PCG-F360 , PCG-F360 (HITACHI LCD) , PCG-F360 (SAMSUNG LCD) , PCG-F370 , PCG-F390 , PCG-F430 , PCG-F450 , PCG-F480 , PCG-F490 , PCG-F520 , PCG-F540 , PCG-F540 (SAMSUNG LCD) , PCG-F540K (SAMSUNG LCD) , PCG-F560 , PCG-F560 (SAMSUNG LCD) , PCG-F560K (SAMSUNG LCD) , PCG-F570 (SAMSUNG LCD) , PCG-F580 , PCG-F580 (SAMSUNG LCD) , PCG-F580K (SAMSUNG LCD) , PCG-F590 , PCG-F590 (SAMSUNG LCD) , PCG-F590K (SAMSUNG LCD) , PCG-F610 , PCG-F630 , PCG-F640 , PCG-F650 , PCG-F650K , PCG-F680 , PCG-F690 , PCG-F801...

SONY VAIO FX SERIES

PCG-FX120 , PCG-FX140 , PCG-FX150 , PCG-FX170 , PCG-R505TE , PCG-R505TS...

SONY VAIO XG SERIES

PCG-XG18 , PCG-XG19 , PCG-XG28 , PCG-XG29 , PCG-XG38 , PCG-XG39 , PCG-XG500 , PCG-XG700 , PCG-XG9...

SONY VAIO Z SERIES

PCG-Z505HE , PCG-Z505HS , PCG-Z505JE , PCG-Z505JS , PCG-Z505LE , PCG-Z505LS...

SONY VAIO PCG-505EX, PCG-505F, PCG-505FX, PCG-505G, PCG-505GX, PCG-505LS, PCG-505TR, PCG-505TS, PCG-505TX, PCG-505VE, PCG-505VX, PCG-505X, SONY VAIO PCG-C1F, PCG-C1MGP, PCG-C1MHP, PCG-C1MV, PCG-C1MVP, PCG-C1X, SONY VAIO PCG-SR5K, PCG-SR7K, PCG-SR9, PCG-SR17, PCG-SR17K, PCG-SR27, PCG-SR27K, PCG-SR33, PCG-SR33K, SONY VAIO PCG-SRX41P, PCG-SRX77, PCG-SRX77P,

PCG-SRX87, PCG-SRX87P, PCG-SRX99, PCG-SRX99K, PCG-SRX99P, SONY VAIO GR
PCG-GR, PCG-GR150K, PCG-GR170K, PCG-GR250, PCG-GR250K, PCG-GR250P,
PCG-GR270, PCG-GR270K, PCG-GR270P, PCG-GR290, PCG-GR290K, PCG-GR290P,
PCG-GR300, PCG-GR300K, PCG-GR370, PCG-GR370K, PCG-GR370P, PCG-GR390,
PCG-GR390K, PCG-GR390P, SONY VAIO PCG-GT1, PCG-GT3/K, SONY VAIO
PCG-V505A, PCG-V505AC, PCG-V505AK, PCG-V505AP, PCG-V505AX, PCG-V505AXP,
SONY VAIO PCG-VX88, PCG-VX88P, PCG-VX89, PCG-VX89K, PCG-VX89K1, PCG-VX89P,
SONY VAIO PCG-Z1A1, PCG-Z1AP1, PCG-Z1AP2, PCG-Z1AP3

Fujitsu Notebook Lifebook Milan, Monte Carlo, Montegro, PenCentra 130, PenCentra 200,
Point 1600. Point 510, 270DX, 280DX, 3700X, 400, 420D, 435DX, 500, 500SR, 520D, 520T,
530, 530T, 531T, 531TX, 535, 535T, 535TX, 555TX, 556TX, 565TX, 585T, 585TX, 600, 635T,
635TX, 655TX, 656TX, 675TX, 690TX, 695, 735DX, 755TX, 765DX, 765TX, 770TX, 780TX,
790TX, Lifebook B2130, B2131, B2175, B2610

Lifebook E330, E335, E340, E342, E350, E360, E362, E6520, E6530, E6541, E6550, E6555,
E6575, E6577, E6595, E6596

Lifebook i4120, i4170, i4177, i4178, i4187, i4190

Lifebook P2000, P2040, P2110, P2120

Lifebook S2000, S4510, S5582, S6010, Stylistic LT C-500, Stylistic LT P-600, Stylistic 1000,
Stylistic 1200, Stylistic 2300, Stylistic 3400, Stylistic 3500, Stylistic 500

Panasonic Toughbook Laptop AC Adapter CF-17, CF-25, CF-27, CF-28, CF-25MKII, CF-33,
CF-34, CF-35, CF-37, CF-41, CF-42, CF-45, CF-47, CF-48 Intel PIII CPU, CF-61, CF-62,
CF-63, CF-71, CF-72 Intel PIII CPU, CF-105B, CF-170, CF-270, CF-370, CF-380, CF-M34,
CF-S51, CF-V21, CF-V21P, CF-V25, CF-V41, CF-V45